



Wall Cladding Installation Guide

v20180618 AU



IMPORTANT:
Read All Sections Before You Start

For the most up to date information, please visit our website @ www.newtechwood.com.au

Prior to installing any composite cladding system, it is recommended that you check with local building codes for any special requirements or restrictions. The diagrams and instructions outlined in this guide are for illustration purposes only and are not meant or implied to replace a licensed professional. Any construction or use of NewTechWood must be in accordance with all local zoning and/or building codes. The consumer assumes all risks and liability associated with the construction and use of this product.

Safety

When dealing with any type of construction project, it is necessary to wear appropriate safety equipment to avoid any risk of injuries. NewTechWood recommends, but is not limited to the following safety equipment, when handling, cutting, and installing NewTechWood: gloves, a respiratory protection, long sleeves, pants, and safety glasses.

Tools

Standard woodworking tools may be used. It is recommended that all blades have a carbide tip. We also recommend using blades with 60+ teeth. Standard stainless steel or acceptable coated deck screws and nails are preferred.

Environment

A clean, smooth, flat, and strong surface is needed to install NewTechWood's products correctly. Please check with local building codes before ever installing any type of decking. If installation does not occur immediately, NewTechWood's products need to be stored on a flat surface at all times.

Planning

Plan a layout for your cladding before starting it to ensure the best possible looking cladding for your project. Building codes and zoning ordinances generally apply to permanent structures, meaning anything that is anchored to the ground or attached to the house. So nearly every kind of cladding requires permits and inspections from a local building department. We recommend drawing out a site plan of your proposed project to minimize errors and achieve the best outcome.

Construction

NewTechWood is NOT intended for use as columns, support posts, beams, joist stringers or other primary load-bearing members. NewTechWood must be supported by a code-compliant substructure. While NewTechWood products are great for retrofits, NewTechWood's products CANNOT be installed over existing cladding boards.

Static

All composite product may be prone to some level of static. Static build up is a phenomenon that may occur with many plastic products and there is no simple answer why some composite products generate more static than others. Location, climate, capped composites, and the amount of time people spend using the products such as decks are all potential factors that can have an impact.

If static is an issue you can use a Heavy Duty Staticide product. This works well, however, it will only give protection for 6 - 8 months. https://www.aclstaticide.com/heavy_duty_staticide.html

Generally, any static issue will lessen after time.

For specific decking static issues, please refer to the Decking Installation Guide.

NewTechWood's products have been tested against EN 1815 - Assessment of Static Electrical Propensity and have received values under the maximum standard of 2Kv.

Ventilation

NewTechWood products CANNOT be directly installed onto a flat surface. They must be installed onto a substructure, so there is adequate and unobstructed air flow behind the cladding to prevent excessive water absorption. A minimum of 25 mm of continuous free area behind the cladding surface is required for adequate ventilation.

Heat and Fire

Excessive heat on the surface of NewTechWood products from external sources such as but not limited to fire or reflection of sunlight from energy efficient window products. Low-emissivity (Low-E) glass can potentially harm NewTechWood products. Low-E glass is designed to prevent passive heat gain within a structure and can cause unusual heat build-up on exterior surfaces. This extreme elevation of surface temperatures, which exceeds that of normal exposure, can possibly cause NewTechWood products to melt, sag, warp, discolour, increase expansion/contraction, and accelerate weathering.









Current or potential NewTechWood customers that have concerns about possible damage by Low-E glass should contact the manufacturer of the product which contains Low-E glass for a solution to reduce or eliminate the effects of reflected sunlight.

Fasteners



NewTechWood cladding is designed to be installed using the (AW08) secret fix clips, for best results. An extra joist should be added if a 90 degree angle cannot be driven into the board. All fasteners should be on their own independent joists. When two board ends meet each other there must be a sister joist. The end of each board must sit on its own joist.

Use white chalk, straight boards, or string lines as templates for straight lines. NEVER USE COLOURED CHALK. Coloured chalk will permanently stain NewTechWood's products and is not recommended.

Wall Cladding Parts

Product	Purpose	Part
AW-02	Starter Profile Used for the installation of the first board	
AW-08	Secret Fix Clips Used at every joist to fix each board to the joist	
T-7	Stand Off's Used on the last wall cladding board	
US09 / US31	Wall Cladding Board	
US44	F-Trim , used at the windows	
US45	H-Trim , used if there is a break between two boards to cover up the gap	
US46	Outside Corner Trim , used on the outside corners	
US47	Inside Corner Trim , used on the inside corners	

Wall Cladding Screws


Product	Purpose	Part
<p>WJ063</p> <p>* M3 x 12</p> <p>SS304</p>	Used when locking the board and installing into wood joists	
<p>* M4 x 80**</p> <p>SS304</p> <p>**depends on the thickness of your joists</p>	Used to install the joist to the wall	

* Note: All screws are based on our recommendation and if the installation requires something different than what is shown, a professional should be consulted before installing.

The following installation guide will use the above screw sizes.

Under Construction


We recommend for the under construction aluminium or pressure treated timber joists. Each cladding board needs to be supported by a joist NO MORE than 500 mm from centre to centre. Extra care is required in order to provide sufficient joisting in and around obstacles such as windows, fascia's, soffits, guttering, ventilation points, etc. Below is an example of the layers that would occur in a typical installation, but a licensed professional should always be consulted prior to any installation.




Joist Installation

A building professional should be consulted regarding vapor barriers and insulation for your project. Where a vapor barrier is to be used, it should be a breathable type and must be positioned behind the joists to allow the cladding a minimum 25 mm airflow.

Joists/battens should be fixed into position at a maximum of 500 mm centres using a suitable Stainless Steel Countersunk Wood/Masonry screw. All joists need to be flat and leveled against the wall surface, use shims if necessary.



Horizontal Installation



Vertical Installation

Locking the Wall Cladding Board

Every AW-08 clip comes with 2 holes. One hole is for fixing the clip to the batten, and the other hole is for the purpose of locking the cladding board to the clip using the WJ063 locking screws (M3 x 12).

PLEASE NOTE: It is important that only one locking screw per length is used. The locking screws help control the expansion and contraction of the cladding boards due to temperature variation. Please see Diagrams 1, 2 and 3 for the correct positioning of the locking screw on each board.

It is recommended using the H Trim in preference to staggered butt joints for a cleaner finish if joining two lengths.




DIAGRAM 1




DIAGRAM 2




DIAGRAM 3

Framing

The frame needs to be completely level before installing any wall cladding boards.

Note: Adequate spacing in the joists is required to keep the cladding boards from bending. Please review page 6 of this installation guide to see what spacing is required.

The wall as shown in Diagram 4 will be installed to replicate different scenarios potentially occurring when installing the wall cladding.




DIAGRAM 4

- 1 Start by fixing the joist onto the wall.



DIAGRAM 5

- 2 Next, the span needs to be measured for the next joist. Please review page 6 for the maximum span allowed from the centre of each joist.

Diagram 7 shows the final installation of the first joist.




DIAGRAM 6



DIAGRAM 7

Inside Corner Trim

- 1 The inside corner will be installed as shown in Diagram 8 by first pre-drilling and then fixing with screws.




DIAGRAM 8

Diagram 9 is an above cross section view of the inside corner after installation. The inside corner was first installed onto the joists and then the boards were slotted into both openings when installed.




DIAGRAM 9

Starting Strip

- 1 The starting strip will now be installed on the bottom of the joists as shown in Diagram 10 by first pre-drilling into the AW-02, and then fixing with screws.
- 2 Repeat step 1 and install the rest of the starting strip onto the rest of the joists. The finished starting strip across the joists can be seen in Diagram 10.



DIAGRAM 10

Wall Cladding Board

- 1 Take a wall cladding board and place the side with the lip down as shown in Diagram 11.




DIAGRAM 11

- 2 Place the AW-08 on the board and install with screws as shown in Diagram 12. Please review page 7 of this installation guide on how to lock the board with AW-08.

Note: A gap of at least 10 mm needs to be left at the bottom of the ground and the lip of the board to allow for expansion and contraction, and ventilation.




DIAGRAM 12

- 3 When you are installing the last board of the wall cladding you will need to first install T-7. The T-7 will be installed onto every joist first and then the wall cladding board will be installed like normal as shown in Diagram 13.

Note: The T-7 is used as a place holder for the last board, so that the board will not slant.




DIAGRAM 13

- 4 After installing the last board, the wall cladding should look like Diagram 14.



DIAGRAM 14

Outside Corner Installation

- 1 Next, take the outside corner and fix it to the side of the wall cladding that is open, as shown in Diagram 15.




DIAGRAM 15

- 2 Fix the outside corner by screwing on the opposite face of the outside corner.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 16

Diagram 17 is an above cross section view of the outside corner after installation. The outside was installed after the wall cladding was installed on one of the walls. Then, the outside corner was pushed into the opened side of the wall cladding and screw fixed from the other side.




DIAGRAM 17

Wall Cladding Board

- 1 Now you are ready to install the other side of the wall as per Diagram 18. Repeat steps 1-2 of starting strip on page 9 of this installation guide.




DIAGRAM 18

- 2 Then, repeat steps 1-3 of wall cladding board on page 10 of this installation guide. Continue to the top for a final finish as shown in Diagram 20.




DIAGRAM 19




DIAGRAM 20

F Trim Installation

- 1 An F trim can now be used to finish off the open side of this wall cladding as shown in Diagram 21 and 22.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 21




DIAGRAM 22

Diagram 23 is an above cross section view of the F trim after installation. The outside was installed after the wall cladding was installed on one of the walls. Then the F trim was pushed into the opened side of the wall cladding and then screw fixed from the other side.




DIAGRAM 23

Wall Cladding Board

- 1 Now the other side of the inside corner wall will be installed. First, attach the AW-02 at the bottom of the wall as per steps 1-2 of starting strip on page 9 of this installation guide..



DIAGRAM 24

- 2 Then, install the wall cladding boards as shown in Diagram 25 by repeating the steps 1-3 of wall cladding board on page 10 of this installation guide.



DIAGRAM 25

- 3 Continue to install the wall cladding boards until the top is reached as shown in Diagram 26.




DIAGRAM 26

H Trim Installation

- 1 Using the H trim, install the H trim on the opened side of the wall cladding, as shown in Diagram 27.




DIAGRAM 27

- 2 Fix the H trim to the joist by screw fixing the H trim and joist.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 28

Wall Cladding Board

- 1 Repeat steps 1-2 of starting strip on page 9 of this installation guide on the section shown in Diagram 29.



DIAGRAM 29

- 2 Next install the wall cladding board on top of the AW-02, and install the clips as per steps 1-3 of the wall cladding board on page 10 of this installation guide.

Note: A gap of at least 10 mm needs to be left between the bottom of the ground and the lip of the board to allow for expansion and contraction and ventilation.




DIAGRAM 30

- 3 Install the rest of the wall cladding boards to the top, as shown in Diagram 31.

Diagram 32 is an above cross section view of the H trim installed. The H trim was installed after the wall cladding was installed onto the wall. The H trim then comes in from the side and is screw fixed to the joist on the other side of the H. Alternatively, the H trim can be installed first by screw fixing and then have the wall cladding boards come in afterwards but this would require the distance of your cladding project pre-calculated.




DIAGRAM 31




DIAGRAM 32

F Trim Installation

- 1 Install the F trim on the open side of the wall cladding as shown in Diagram 33.




DIAGRAM 33

- 2 Fix the F trim to the joist by screw fixing into the F trim to the joist as shown in Diagram 34.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 34

Wall Cladding Board

- 1 Take the F trim and cut them to the length of the top of the cladding structure you are installing on, as shown in Diagram 35.




DIAGRAM 35

- 2 Cutting out a notch at both ends might be required to ensure that it fits around the joist as shown in Diagram 36.




DIAGRAM 36

- 3 Now face fix the cut pieces to the tops of the joists as shown in Diagram 37.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 37

Window Installation

- 1 Windows should be installed after all wall cladding has been installed on the wall, as shown in Diagram 38.

Note: This installation of the window will be done on joists and framing that are on timber.

If installation is done on brick or concrete wall framing, metal joists, or timber, joists need to be added first in order to install the boards onto that structure. Installing directly on brick or concrete is not recommended.




DIAGRAM 38




DIAGRAM 40

- 2 Take the wall cladding board and cut down the middle to create a rectangle to fit in the window as shown in Diagram 39.




DIAGRAM 39

- 3 Take the cut pieces and install them to the frame of the window as shown below in Diagram 40 and 41.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 41

- 4 Take the F trim and cut to match the corners of the window as shown below in Diagram 42.




DIAGRAM 42

- 5 Install the cut F trim pieces over the cut composite wall cladding, as show in Diagrams 43 and 44.

Note: Always pre-drill before screwing unless using composite screws designed for non pre-drilling. The distance between each screw should be no more than 300 mm centre to centre.




DIAGRAM 43




DIAGRAM 44

- 6 The completed window installation should look like Diagram 45.




DIAGRAM 45



Wall Cladding Installation Guide

v20180618 AU

©2017 Distributed in Australia by:
Urban Direct Wholesale Pty Ltd
Unit 1, 5 Erceg Road
Yangebup, WA 6164, Western Australia Email:
info@urbandirectwholesale.com.au

NewTechWood is a registered trademark of Huidong Meixin Plastic Lumber Products Manufacturing Co., Ltd. To obtain a copy of the most current version of this installation guide, visit us online at www.newtechwood.com.au

